

STEP BY STEP

LIMECRETE

MICROCEMENT FOR FLOORS AND WALLS

LUXURY
CONCRETE

NON ABSORBENT SURFACES: CERAMIC TILES/TERRAZZO/MARBLE...

ABSORBENT SURFACES: CEMENT/SELF LEVELING SCREED...

1

FILL THE JOINTS

Fill in the joints with Concrete Base
Drying Time: 24 hours
Sand: Grit 40

PRIMACRETE ABS

1 layer as primer
Drying Time: 30 minutes

2

PRIMACRETE PLUS + MESH

1 layer as primer sticking the mesh
Drying Time: 30 minutes / max. 24 hours

LIMECRETE EXTRA/BASIC + MESH

1 layer without pigment sticking the mesh
Drying Time: 3 hours
Sand: Grit 40

3

LIMECRETE EXTRA/BASIC

1 layer without pigment
Drying Time: 12 hours
Sand: Grit 40

LIMECRETE EXTRA/BASIC

1 layer with pigment
Drying Time: 24 hours
Sand: Grit 40

4

LIMECRETE EXTRA/BASIC

1 layer with pigment
Drying Time: 24 hours
Sand: Grit 40

LIMECRETE EXTRA/BASIC/MEDIUM/THIN

1 layers with pigment
Drying Time: 24h
Sand: Grit 80

5

LIMECRETE EXTRA/BASIC/MEDIUM/THIN

1 layers with pigment
Drying Time: 24h
Sand: Grit 80

PRIMACRETE FINISH

2 layers
Drying Time: 4 hours between layers
Sand: Grit 400"

6

PRIMACRETE FINISH

2 layers
Drying Time: 4 hours between layers
Sand: Grit 400

CONCRETE FINISH WT

2 layers
Drying Time: 12-24 hours between layers
Sand: Grit 400 (only 1st layer)

7

CONCRETE FINISH WT

2 layers
Drying Time: 12-24 hours between layers
Sand: Grit 400 (only 1st layer)

LUXURY
CONCRETE

Luxury Concrete SL / B98177538
C/ Lepanto 9, 3
46008 Valencia, España
+34 910 028 940
info@luxuryconcrete.eu
www.luxuryconcrete.eu